

1 First run

Set the scale stable and connect the power of the ESP32.

The first run is displaying:








The ESP32 board opened a Wifi Hotspot named 'CG-B'.

You can connect your phone/laptop on this SSID (no password).

Your phone/laptop is not going to detect any internet connection, this is normal, stay connected and use your browser to go to the provided address:

http://172.16.19.1/

2 Configuration



You are now in the configuration of the CG scale.

- 1. Apply some pressure with your hand on each load cell to verify the build. You should see the number moving in each front / rear display.
- 2. Take a working precision scale and measure a small heavy object (>200gr).
- 3. Put this object on a load cell. You should see a huge increment in the front or rear lc display
- 4. Increment the divider to match the real object weight, typical values are between 500 and 1000.
- 5. Do the step 3-4 for the other LoadCell
- 6. Position rod supports on the Scale and mesure precisely each distance (front/rear rods and front/leadingEdge rods)
- 7. Go to Top/Left menu and click 'Save config'


Each time you change the position of the rod supports, you will need to do the step 6.

Step 7 is not mandatory but you will lose your new parameters upon reboot.

3 Tare

With the scale empty (but with rods and everything ready), go to the Top/Left menu and select "Tare empty".

Tare procedure takes ~5 seconds.



4 Usage

Your CG scale is now fully operationnal, you can put a model on the support rods with the LeadingEdge of the wing against the LE rod.

On the standalone OLED display of the ESP32, you will see a display like this one:



Or via the 'live scale' menu item on your phone:

